



HOW-TO GUIDE

TRANSCENDENT RECORDERS: CONNECTING TO DEVICE VIA NAT WITH WEB BROWSER




PLEASE NOTE:

Complete User Guide, Software, Tools, and Updates are available online. Scan the QR Code or visit:
<https://vitekccctv.com>


Transcendent Recorders

Connecting to Recorder through web browser using NAT


Click on Start (Circle with 4 squares)




Log on to recorder and select settings



Main Menu will appear, then select **Network**



After entering the Network section you will see across the top sub sections of Network, click on **NAT** which will bring you to the below screen, Enable the NAT and click Apply, next to NAT Status will inform you if it was successful or failed, if failed appears, check you network connections. The QR code is for mobile devices to scan, under the QR code is the NAT code, copy these letters and numbers down.



On your computer.

Open web browser and go to address www.autonat.com

Recorders must be on 1.3.8(DVR) 1.4.5(NVR) firmware for Chrome, Firefox, Edge and Safari to work

Firmware below these must use Internet Explorer or Edge in IE mode



Enter QR numbers and letters in the field saying QR code number

Then enter Username and Password for the recorder and click login.

This will bring you to the recorders live screen

